



1. WinAIR Hanging Bracket

Installation

- Install WinAIR pressure gauge onto Hanging Bracket with the short screws supplied in the WinAIR packaging
- Mount the assembly as required