



1. WinAIR Surface mounting bracket

## Installation

- Install WinAIR pressure gauge onto the Surface Mounting bracket by using the small screws supplied in the WinAIR packaging
- Install the complete assembly onto a panel or wall as required

