



1. WinAIR flush mounting bracket

Installation

- Install WinAIR pressure gauge onto the Flush Mounting bracket by using the small and long screws, along with the bracket supplied in the WinAIR packaging
- Install the complete assembly onto a panel or wall as required